

Мобилно интернет устройство PRIVILEG MID-10

Кратко ръководство на потребителя

1. Външен изглед на устройството



2. Първи стъпки

2.1 Зареждане на батерията

Захранващ адаптер



Зареждане на батерията

1. При свързване на захранвания адаптер, индикаторът на батерията започва да свети в червено. Когато батерията се зареди докрай, индикаторът угасва. След откачане на адаптера, индикаторът не свети.

2. По време на зареждане можете да използвате вашия MID-10.

Забележка:

Когато работите и зареждате устройството, зареждането ще трае по-дълго.

2.2 Използване на картата-памет

Поставяне на картата-памет:

Поставете картата-памет в слота. Натиснете в слота, докато чуете леко щракване. В горния ляв ъгъл на екрана ще видите известие, че SD картата е готова за използване.

Пуснете "File Browser". Изберете "SD card", за да прегледате съдържанието на картата.

Изваждане на картата-памет:

Затворете всички приложения или документи, които са били отворени от картата.

Натиснете леко картата навътре, за да се „отключи“. Тя ще се подаде леко навън. Извадете я. В горния ляв ъгъл на екрана ще видите известие „SD картата е извадена“.

Забележка:

1. Поставете картата в правилна ориентация, в противен случай може да я повредите.

2. Ако картата е „заключена“, тя не може да се форматира или изважда.

3. Не поставяйте и изваждайте картата на кратки интервали, това може да я повреди.

4. Използвайте карти отrenomирани производители за избягване на несъвместимост.

2.3 Изваждане и поставяне на карта-памет и USB диск

Моля, не изваждайте картата-памет или USB-диска, докато използвате файлове записани на тях - снимки, видео, или музика. Директното изваждане на картата или външното USB устройство може да ги повреди, а таблета да се изключи с цел защита. За правилното изваждане, вижте "2.2 Как да използвате картата-памет"; преди да извадите USB-диска, затворете всички документи или програми, отворени или стартирани от него.

2.4 Пространство за съхранение на данните

Устройството има разнообразни възможности за съхранение на информацията: вътрешна памет, USB-диск и карта-памет. Вътрешната памет е вградена в устройството, тя може да се използва само за съхранение на системните файлове. USB-диска и картата-памет могат да бъдат с различен капацитет; поддържаният максимален капацитет за картата-памет е 32GB.

2.5 Включване и изключване

1. Включване: При включен захранващ адаптер, натиснете продължително (2 сек.) бутона за захранване, за да изведете Началния экран.



Плъзнете иконата за отключване, , за да влезете в Главния экран.

2. Изключване: Натиснете продължително (4 сек.) бутона за захранване, и системата ще изведе диалогов прозорец. Плъзнете иконата за отключване . С продължително натискане (8 сек.) на бутона за захранване можете да изключите машината.

2.6 Свързване с Интернет

Свързване с Интернет чрез Ethernet порт:

Свържете мрежов кабел към Ethernet LAN порта на устройството. Можете да получите IP адреса автоматично, или да го поставите ръчно. В горния десен ъгъл на екрана се появява икона ETH.

Свързване с Интернет чрез Wi-Fi:

1. Щракнете бутона MENU за извеждане на менюто, и изберете „Системни настройки“ ("System Settings");
2. Изберете „Безжични и мрежи“ ("Wireless & networks") в менюто за настройки;

3. Изберете в прозореца да отворите Wi-Fi;
4. Отворете Wi-Fi настройки;
5. В изведенния списък ще видите всички точки за достъп (AP) в околността. Докоснете желаната връзка (име) за свързване към AP;
6. Ако преди това има успешна връзка към тази AP, информацията за AP ще бъде съхранена в изскучащия прозорец. С избирането на "Connect" (свързване) започвате връзката, с "forget" (забрави) изтривате AP информацията;
7. Ако AP не е криптирана, в изскучащия прозорец изберете "Connect", за да стартирате връзката;
8. Ако AP е криптирана, в изскучащия прозорец въведете парола и изберете "Connect", за да стартирате връзката;
9. Когато интернет връзките са успешни, в лентата на състоянието се появява икона за безжична връзка.

3. Операции за въвеждане

3.1 Чувствителен на допир еcran

Екранът следи допира и траекторията на пръста. Вижте по-долу начина на работа с него:

Забележка: Моля не поставяйте предмети на повърхността на екрана, за да не го надраскате или пукнете.

Кратко докосване: Изберете икона и докоснете кратко иконата или опциите;

Дълго докосване: при докосване и задържане на икона, можете да я изведете на десктопа.

Провличане и пускане (Drag and Drop): С провличане на десктопа можете да превключвате между три екрана.

Вместо върха на пръста можете да ползвате „писалка“ (стилус).



4. Десктоп

4.1 Лента на състоянието

В горната част на екрана е лентата на състоянието, в която се появява

информация за SD картата, мрежата, статус на батерията, часа, смяната на силата на звука и пр.



4.2 Началният экран

Началният (Главният) экран на таблета има два режима: Десктоп приложения и Екран с приложения. Вижте по-долу Десктоп режима:



Щракнете иконата  за влизане в екрана на Приложенията:



Докоснете иконата , за да влезете в Десктоп экрана.

4.3 Използване на приложенията на десктопа

Потребителите могат да добавят, премахват уиджети, икони за приложения. Самите икони могат да бъдат премествани в екрана и изтривани.

Когато сте в Началния экран с десктоп икони, докоснете и задръжте икона за да я премествате навсякъде по екрана, можете да ги премествате в появяващото се кошче, за да ги изтриете и пр.

5. Управление на приложенията

5.1 Инсталлиране и деинсталлиране

Инсталиране

За да инсталирате софтуер от трета страна, моля първо влезете в браузъра. След това открийте APK файла в картата-памет. докоснете файл от горния екран, за да изведете екрана за инсталлиране, и щракнете бутона "Install"

Деинсталлиране

За да деинсталирате инсталирания допълнително софтуер, натиснете MENU → Settings → Application → management application.

Щракнете върху приложението, което искате да деинсталирате, щракнете Uninstall (деинсталрирай), и ще влезете в екрана за потвърждение. Щракнете OK за да деинсталирате приложението.

5.2. Управление на безжичната комуникация

Wi-Fi

За вкл./ изкл. на Wi-Fi, натиснете MENU → Settings → Wireless & networks → Wi-Fi.

Wi-Fi настройки

За настройка и управление на безжичната точка за достъп, натиснете MENU → Settings → Wireless & networks → Wi-Fi settings.

5.3. Приложения

Управление

За да управлявате и премахвате инсталирани приложения, натиснете MENU → Settings → Applications → Management applications (Управление на приложението).

Разработка

За да настроите опциите за разработване на приложения, натиснете MENU → Settings → Applications → Development.

6. SD карта, свободен капацитет

Сторидж устройства

Натиснете MENU → Settings → TF card & device storage → Storage devices (Сторидж устройства). Ще може да видите свободното място и общия обем на TF/SD картата.

Безопасно изваждане на TF/SD картата

За да извадите безопасно SD картата от устройството, натиснете MENU → Settings → TF card & device storage → Unmount SD card (Извадете SD картата).

Вътрешна памет

Натиснете MENU → Settings → TF card & device storage → internal device storage (Вътрешна памет), и можете да видите капацитета (общ, свободен) на вътрешната памет

7. Заключване на MID-10

Заключване на екрана/устройството:

1. При бездействие (не натискате никакви бутони), устройството автоматично ще заключи екрана в съответствие със системните настройки;
2. Натиснете кратко бутон захранване в който и да е системен екран, за да изключите подсветката (екранът угасва) и заключите екрана.

Отключване на экрана/устройството:

Когато системата е в режим „сън”, с кратко натискане на бутона Захранване ще влезете в экрана за отключване, пълзнете иконата за отключване.

8. Важни инструкции за безопасност

Винаги следвайте тези основни инструкции за безопасност, когато използвате Таблета. Това ще намали опасността от пожар, електрически удар и нараняване.

- Не излагайте продукта на дъжд или влага.
- Дръжте го далеч от пряка слънчева светлина и източници на топлина.
- Пазете захранващия кабел. Не го разполагайте там, където често минават хора, за да не го настъпват и не се спъват в него. Особено внимавайте за точката, в която кабелът влиза в устройството.
- Използвайте само AC адаптера включен в комплекта на устройството. Использоването на друг адаптер може да унищожи гаранцията.
- Не махайте капака. В устройството не може да се ремонтира от вас.

Почистване на устройството

Внимателно почиствайте экрана - за почистване на прах и пръстови отпечатъци използвайте меко парче плат предназначено за оптика.

Mobile Internet Device PRIVILEG MID-10

Quick User Guide

1. Product views, description



2. Getting Started Guide

2.1 Charging the Battery

Power Adapter



Charging the Battery

1. Connect the power adapter; the battery charge indicator turns red, indicating charging. When the battery is fully charged, the indicator turns off. After unplugging the power adapter, the indicator always stays off.

2. During Battery Charging, the user can operate the Privleg MID.

Note:

Charging time will be longer when you operate and charge the device at the same time.

2.2 How to use the Memory Card

Insert the memory card:

Insert the memory card in the Card slot. Use a fingertip to put the card into the slot until a "click" sound is heard. The upper left corner of the screen will prompt: "SD card is ready".

Browsing files in the memory card:

Run "File Browser". Select "SD card", then "Open" to browse the contents of the Card.

Remove the memory card:

Close all applications or documents which have been opened from the card.

Press the card lightly. It will be ejected partly. Pull the card out. The upper left corner of the screen will prompt "SD card has been removed".

Note:

1. Insert card to in the correct position. Otherwise the card will be damaged.
2. Once the card has been locked, it can not be formatted or written.
3. Don't insert and remove the card repeatedly in a short time. It may cause the card damaged.
4. Suggest using major brands of memory card to avoid any incompatibility.

2.3 Remove and insert memory card and U disk

Please don't remove the memory card and U disk while you are using the files in it - photos, videos or music - this may cause the memory card and U disk to be damaged and the device may exit automatically for protection. For memory card removal, please refer to "2.2 How to use Memory Card". In order to remove the U disk, please close all applications or documents which have been opened from the U disk.

2.4 Storage Space

The device has three storage spaces: internal device storage, U disk and memory card. The internal storage device is not shown, it can only be used to store system

files; the U disk and memory card have their own its specific capacity, the device supports maximum 32GB card.

2.5 Power On and Off

1. Power On: When power adaptor is plugged, User can long press (2seconds) Power button to enter the Window Platform.



In the main screen, slide the unlock icon .

2. Power Off: User can long press (4 seconds) the power button, then the system will pop up a dialog box for equipment selection.

Slide the unlock icon The device can be shut down. User can long press (8 seconds) the power button to shut down the machine.

2.6 Connecting to the Internet

Connecting to the Internet via Ethernet:

Insert the network cable into the Ethernet port, You can get the IP address automatically and you can also select to set the IP address manually. The upper right corner of the screen will show ETH icon.

Connecting to the Internet by Wi-Fi:

1. Click MENU button to pop-up the menu, and select "System Settings";
2. Select "Wireless & networks" in the settings menu;
3. Select the box to open Wi-Fi;
4. Open Wi-Fi Settings;
5. All the AP in the vicinity will be listed, select the name of AP you want to connect to;

6. If the AP connection was successful before, the AP information will be saved in the pop-up window. Select "Connect" to connect, choose "Forget" to remove AP information;
7. If the AP is not encrypted, select "Connect" in the pop-up window to start connection;
8. If the AP is encrypted, enter the password in the pop-up window, and click "Connect" to start connection;
9. When Internet connections are successful, the wireless connection icon appears in the status bar.

3. Input Operations

3.1 Touch Screen

The Touch Screen senses the finger movements:

Note: Please do not place objects on the touch screen surface, they may scratch or crush it.

Click: Select an icon, click on it, and then you can select the icon or an option;

Long press: Select a single icon, long press it, and then you can drag it to the desktop display.

Drag and Drop: You can switch between three screens of the desktop.

In the process of using the screen, you can use a pencil instead.



4. Desktop

4.1 Status Bar

The top of the screen is reserved for the status bar, and displays SD card, network, battery status, time and volume change, and other notifications...



Battery status icon



Time display



Volume reduction icon



Volume increase icon



Shortcut menu icon



Back icon



Desktop icon



Picture capture icon



Ethernet icon



Wi-Fi status icon



3G icon

4.2 The Home screen

The Tablet main screen contains two modes: Desktop Gadgets mode and Application mode, the two modes can be switched via the central button, Desktop Gadgets screen is shown below:



Click the icon to enter the screen of Applications



Click the icon , to enter Desktop Gadgets mode.

4.3 The use of desktop gadget

Users can add, remove, install a desktop gadget, you can add, remove application icons, the icon can be moved to adjust the position.

When in Desktop Gadgets screen, press the small tool icon, the screen pops up a small box, the central pop-up trash in the shortcut bar appears.. You can drag the icon anywhere on your desktop, you can also directly drag into the trash box to delete it.

5. Application Management

5.1 Install and Uninstall

Install

To install third-party software, please first enter File Browser. Then find the APK file from the memory card, click on the.apk file to pop up the installation screen. Then click Install button, and then the device will begin to install the application.

Uninstall

To uninstall installed third-party software, press MENU → Settings → Application → management application. Click the application you want to uninstall, the uninstall screen will pop-up. Click Uninstall to enter the confirmation uninstall interface, click OK to uninstall the application, and it will be uninstalled from the device.

5.2 Wireless Communication management

Wi-Fi

If you want to open and close the Wi-Fi connection, please press MENU → Settings →Wireless & networks→ Wi-Fi.

Wi-Fi Settings

If you want to set up and manage the wireless access point, please press MENU→ Settings →Wireless & networks → Wi-Fi settings.

3G network settings

If you want to set up the 3G network, please press MENU→ Settings →Wireless & networks → 3G settings.

5.3 Applications

Unknown Source

After checking, you will be able to install an application, which is not provided by the App Market.

Manage applications

In order to manage and remove installed applications, press MENU → Settings → Applications → Management applications.

Development

In order to set options for application development, please press MENU → Settings → Applications → Development.

6. SD card & device storage

Here you can unmount the SD card (TF-card), and view available storage space

Storage devices

Press the MENU → Settings → TF card &device storage →Storage devices, and see the available space and the total space of the SD Card (TF card).

Unmount SD Card

In order to remove the SD card in a safe way, please press the MENU → Settings → TF card &device storage → Unmount SD card.

Internal device storage

Press the MENU → Settings → TF card &device storage →internal device storage, and check the internal device storage space

7. Locking the MID

Screen / device lock:

1. When the screen is idle (no buttons pressed for a certain time), the device will lock the screen automatically in accordance with the system settings;
2. Short press the power button in any system interface to turn off the screen backlight and lock the screen.

Screen / device unlock:

When the system is in hibernation, press shortly the power button to enter the lock screen interface, slide the unlock icon, and you can unlock the screen.

8 Important Safety Precautions

Always follow these basic safety precautions when using your Tablet. This

reduces the risk of fire, electric shock, and injury.

- Do not expose this product to rain or moisture.
- Keep the device out of direct sunlight and heat sources.
- Protect the power cord. Route power cords so that they are not likely to be walked on or pinched by items placed on or against them. Pay particular attention to the point where the cord connects to the device.
- Only use the AC adapter included with the device. Using any other power adapter voids your warranty.
- Do not remove the cover. There are no user-serviceable parts inside.

Cleaning your Device

Treat the screen gently. For cleaning fingerprints or dust from the screen, we recommend to use a soft, non-abrasive cloth such as a camera lens cloth.